

ETC Key Shortcuts

Eos Family Consoles

Eos Windows and macOS Keyboard Shortcuts

Eos Function	Windows Shortcut	macOS Shortcut
Shortcut List	Alt /	
	?	
0	0	
1	1	
2	2	
3	3	
4	4	
5	5	
6	6	
7	7	
8	8	
9	9	
. (Decimal)	. (Decimal)	
- (Minus)	- (Minus)	
+ (Plus)	= (Equals)	
	+ (Plus)	
+%	Shift =	
	Control Alt =	
-%	Shift -	
	Control Alt -	
/	/	
Augment3D (A3D) Camera Up	Up Arrow	
A3D Camera Up (Edit Mode)	W	
A3D Camera Forwards	Shift Up Arrow	
A3D Camera Forwards (Edit Mode)	Shift W	
A3D Camera Left	Left Arrow	
A3D Camera Left (Edit Mode)	A	
A3D Camera Down	Down Arrow	



ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
A3D Camera Down (Edit Mode)	S	
A3D Camera Backwards	Shift Down Arrow	
A3D Camera Backwards (Edit Mode)	Shift S	
A3D Camera Right	Right Arrow	
A3D Camera Right (Edit Mode)	D	
About	Y	
Address / Dimmer	Alt A	
All NPs	Control N	
Assert †	Control W	
Assert (Playback) †	Control Alt A	
At	A	
	@	
	*	
Back (ECU)	Escape	
Beam Filter	Control B	
Beam Palette	Alt B	
Blind	F2	
	Control 2	
Block	B	
Capture	Control Alt P	
Clear	Backspace	
Clear Command Line	Shift Backspace	
	Control Alt Backspace	
Clear Label	Control Backspace	
Color Filter	Control C	
Color Palette	Alt C	
Color Path	Control Alt W	
Copy To	C	
Cue	Q	
Cue Only / Track	X	
Data	Control D	
Data Mode	Control Shift D	

ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
Delay	D	
Delete	Delete	Fn Delete
Displays	F9	
	Control 9	
Effect	Alt E	
Encoder Display (Gio) †	Control Alt \	
Encoder Page Color ^†	Control Alt [
Encode Pager Focus ^†	Control Alt ,	
Encoder Page Form ^†	Control Alt ;	
Encoder Page Image ^†	Control Alt]	
Encoder Page Intensity ^†	Alt .	
Encoder Page Shutter ^†	Alt ,	
Enter	Enter	
Escape	Escape	
Expand	F5	
	Control 5	
Fader Page †	V	
Fan †	W	
FlexiChannel	F3	
	Control 3	
Focus Filter	Control F	
Focus Palette	Alt F	
Follow / Hang †	Shift D	
	Control Alt D	
Format	F4	
	Control 4	
(Scroller) Frame	Control Alt C	
Freeze †	Control Alt F	
Full	F	
Go	Spacebar	
Go To Cue	Control G	
Go To Cue Zero	Control Alt G	

ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
Group	G	
Help	Alt /	
Highlight †	\	
	Control Alt H	
Home	Home	Fn Left Arrow
	Control H	
Intensity Block †	Shift B	
	Control Alt B	
Intensity Filter	Control I	
Intensity Palette	Alt I	
Label / Note	L	
Last	Page Up	Fn Up Arrow
	Control ,	
Learn	Alt L	
Level	Control V	
Live	F1	
	Control 1	
Load	Control Alt L	
Macro	M	
Macro 801*	Control Alt 1	
Macro 802*	Control Alt 2	
Macro 803*	Control Alt 3	
Macro 804*	Control Alt 4	
Macro 805*	Control Alt 5	
Macro 806*	Control Alt 6	
Macro 807*	Control Alt 7	
Macro 808*	Control Alt 8	
Macro 809*	Control Alt 9	
Macro 810*	Control Alt 0	
Magic Sheet (MS)	Alt M	
MS Editor Grid Toggle	Control I	
MS Editor Reset Zoom	Control 0	

ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
MS Editor Zoom to All	Control 1	
MS Editor Zoom to Selection	Control 2	
MS Editor Center on Selection	Control 3	
MS Editor Flip Vertical	Control F	
MS Editor Flip Horizontal	Control Shift F	
MS Editor Mirror	Control M	
MS Editor Group	Control G	
MS Editor Ungroup	Control Shift G	
MS Editor Normal Layout	Control E	
MS Editor Renumber (By Click)	Control Shift R	
MS Editor Stretch	Control S	
MS Editor Cut	Control X	
MS Editor Copy	Control C	
MS Editor Paste Renumber	Control Shift V	
MS Editor Paste Duplicate	Control V	
MS Editor Clear Selection	Control D	
MS Editor Renumber In Item	Control R	
Manual Override	Control Alt M	
	Control Alt N	
Mark †	K	
	Control Alt K	
Mirror Start	Alt F1	
Mirror Stop	Alt F2	
ML Controls	F7	
	Control 7	
More Softkeys (More SK)	Alt 7	
Next	Page Down	Fn Down Arrow
	Control	
Off	Control Alt O	
Offset	Control O	
Out	O	
Page Left	Left Arrow	

ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
Page Right	Right Arrow	
Page Up	Up Arrow	
Page Down	Down Arrow	
Parameters (Display)	Control D	
Park	Alt K	
Part	P	
Patch	;	
Pixel Map †	Alt X	
Preset †	Alt P	
Query †	Control Q	
Rate	Control Alt R	
Recall From	E	
Record	R	
RecordOnly	Control R	
Release	Control Alt S	
Rem Dim	H	
Scroll Lock	Control 6	
Select	Control Enter	
Select (ECU)	Return	
Select Active	Control A	
Select Last	Control L	
Select Manual	Control M	
Setup	Alt S	
Shift	Z	
Snapshot	Control S	
Sneak	N	
Softkey 1	Alt 1	
Softkey 2	Alt 2	
Softkey 3	Alt 3	
Softkey 4	Alt 4	
Softkey 5	Alt 5	
Softkey 6	Alt 6	

ETC Key Shortcuts

Eos Family v3.3.0

Eos Function	Windows Shortcut	macOS Shortcut
Spacebar Disable	Alt G	
Staging Mode	F6	
Stop / Back	Control Spacebar	
	Control Alt Q	
Stop Effect	Control Alt E	
	Shift Alt E	
Submaster	S	
Tab	Tab	
Time	I	
Time (Displays)	Control Alt I	
Timing Disable	Control Alt T	
Toggle Hotkeys	F8	
	Control 8	
Trace †	J	
Thru	T	
Undo	Control X	
Update	U	
Virtual Keyboard	Control K	
Workspace] or [
Zoom Selected Display	Left Mouse Button + Scroll Wheel	

** Some key combinations are not available on all physical keyboard layouts*

^ Alternatively use Encoder Display + category to change the encoder pages

† Commands are not available on Element Classic

Notes

- Scroll Lock must be off to use keyboard shortcuts.
- Some international keyboards require that you disable **{Use Shift Key As Eos Shift}** in **Setup > Device > Face Panel > Input Devices**. Use Z as shift to access shortcut functions in these cases.
- To enable Eos functions on macOS function keys, navigate to **System Preferences > Keyboard** and enable the "Use all F1, F2, etc... keys as standard function keys" setting.
- If a separate shortcut is not listed for macOS, the shortcut is the same as the Windows version.

ETC Key Shortcuts

Eos Family v3.3.0

Eos Console Hardkey Shortcuts

Displays

- **[Data]** (maintained press) - toggles the display to show data living under referenced data. Keep **[Data]** depressed to page. **[Data] & [Data]** locks this display.
- **[About] & [Data]** - locks the display to the absolute data display.
- **[Time]** (maintained press) - toggles the display to show discrete timing. Keep **[Time]** depressed to page.
- **[About] & [Time]** - locks the display to discrete time display. Press **[About] & [Time] [Time]** to unlock, or temporarily display discrete time.
- **[Data] & [Focus] / [Color] / [Beam]** - to expand/ suppress categories on displays. (Ion)
- **[Data] & {Parameter Tiles}** - to suppress/ display individual parameters from the display when not in summary view. (Ion)
- **[Params] & [Focus] / [Color] / [Beam]** - to expand/ suppress categories on displays. (Ti/ Eos/ Gio)
- **[Params] & {Parameter Tiles}** - to suppress/ display individual parameters from the display when not in summary view. (Ti/ Eos/ Gio)
- **[Displays] & [Level Wheel]** - controls the Main slider in Brightness Settings.
- **[Displays] [Displays]** - resets the CIA to the browser.
- **[About] & [Path]/[Color Path]** - toggles the display to show the color paths.
- **[Shift] & [Select]** - reset display columns.
- **[Shift] & [Tab]** - clear all tabs on the current monitor (but keep locked frames) (Does not clear tab 1 and 2).
- **[Shift] & [Tab] [Tab]** - clear all tabs on all monitors (but keep locked frames) (Does not clear tab 1 and 2).
- **[Shift] & [Tab] [Tab] [Tab]** - clear all tabs on all monitors (including locked frames) (does not clear tab 1 and 2).
- **[About] & [Label]** - toggles the Live / Blind display to show reference labels or numbers, based on setup.
- **[About] & [Label] [Label]** - double press to lock reference labels on. Press **[About] & [Label]** again to unlock.
- **[Shift] & [Live/ Blind]** - advances the displays to the next instance of Live or Blind.
- **[Live]** (when already in Live) - re-syncs the selected cue to the most recently activated cue.
- **[Blind]** (when already in Blind) - re-syncs the selected cue to the live selected cue (when blind cue has been changed or when preserve blind cue has been enabled).
- **[Flexi] & [Time]** - to invoke Flexi time view on displays.
- **[Format] & [Level Wheel]** - zooms the display in focus.
- **[Tab] & [Up/Down Arrow]** - cycle workspaces.
- **[Tab] & [Left/Right Arrow]** - move displays.
- **[Tab] & [number]** - open or focus specific displays.
- **[Flexi] & [.]** - turns on Flexi multicells off mode. Press again to turn off.
- **[About] & [Live]** - displays the DMX values.
- **[About] & [Mark]** - displays the mark cue used by the channels.
- **[About] & [Next]/[Last]** - displays the next cue that the channels move in or the last cue that the channels moved in.
- **[About] & [Park]** - displays the parked levels.
- **[About] & [Part]** - displays the cue part number for each parameter.
- **[Expand] & [Effect]** - opens the Effect Status Display (Tab 8).

ETC Key Shortcuts

Eos Family v3.3.0

Operations

- **[At] [Enter]** - removes move information from selected channel/parameters.
- **[At] [At]** - set to Level (as defined in Setup).
- **[Color] (Encoder Paging Key) & Encoder Movement** - hold Color Point while adjusting parameters.
- **[Copy To] [Copy to]** - posts Move To on the command line.
- **[Full] [Full]** - sets selected channels intensity to "full" and self terminates.
- **[Label] [Label]** - appended to a record target command, clears the current label, this includes show file labels.
- **[Recall From] [Recall From]** - posts Recall From Cue to the command line.
- **[Record] [Record]** - posts Record Only to the command line.
- **[Select Active] [Select Active]** - Select Active minus submaster contributions.
- **[Shift] & [Select Active]** - posts Select Non-Sub Active.
- **[Shift] & [Enter]** - repeats last command line, unterminated; loops last five commands.
- **[Shift] & [At]** - recalls last channels and parameters without terminating; loops last five commands.
- **[Shift] & [Block]** - posts Intensity Block to the command line.
- **[Shift] & [Clear]** - clears the command line.
- **[Shift] & [Delay]** - posts follow.
- **[Shift] & Encoder Paging Key** - posts the category to the command line. For beam subcategories, press Image, Form or Shutter twice to post Beam. (Ion/Gio)
- **[Shift] & Encoder Movement** - accesses fine mode.
- **[Shift] & Encoder Push/ Toggle** - posts the parameter to the command line. (Ion)
- **[Shift] & Gel Tile** - cycles through three modes of Brightness.
- **[Shift] & [Full]** or **[Shift] & [Out]** - flash on or flash out.
- **[Shift] & [+]** or **[Shift] & [-]** - +% or -%.
- **[Shift] & [Highlight]** - appends highlight to the current channel selection.
- **[Shift] & [Label]** - opens the existing cue note for the selected cue or creates a new one.
- **[Shift] & [Select Last]** - posts additional channel selection options to the softkeys.
- **[Shift] & [Sneak]** - makes manual data un-manual.
- **[Shift] & [Update]** - shortcut to Save.
- **[Shift] & restore manual faders** - reset faders to zero without asserting control.
- **[Shift] & {Direct Select}** - posts DS to the command line without terminating.
- **[Shift] & [Next]** or **[Shift] & [Last]** - advances the cue without changing channel selection.
- **[Sneak] [Sneak]** - releases NPs of selected channels and self-terminates.
- **[Timing Disable] & [Go]** or **& [Back]** - cuts the next cue or cuts the last cue.
- **[Thru] [Thru]** - **[Thru]** command accesses only channels displayed in the current Flexi state (unless the range specified is not in the current display). **[Thru] [Thru]** selects the range regardless of the flexi mode.
- **[Trace] [Trace]** - forces a previously inactive light to track its new intensity setting backwards.
- **[Undo]** - clears an unterminated command line. Otherwise opens undo controls.
- **[Update] & [Sub Bump]** - to update a specific submaster.
- **[n] [At] [/] [/] [m] [Enter]** - sets direct DMX value (m) for channel (n).
- **[Shift] & [Delay] [Delay]** - posts hang to the command line.
- **[Shift] & [About]** - opens a command line search window.
- **[Shift] & [.]** - posts minus cells to the command line. This is for use with multicell fixtures.
- **[.]** - posts multicell fixture cells or cells only to the command line when used after channel numbers.
- **[Shift] & [Int Palette]** - posts preset on the command line (Element & Element 2).
- **[Displays] & [Record]** - puts a marker in the log file.

ETC Key Shortcuts

Eos Family v3.3.0

Face Panel

- **[Shift] & [Escape]** - to lock and unlock face panel.
- **Encoder Paging Keys & [Number]** - pages to the desired encoder control page.
- **[Escape] & Encoder Paging Keys** - locks the encoders. Press any encoder page button to unlock.
- **[Flexi] & Encoder Paging Key** - to invoke flexi encoder states.
- **[Fader Controls] & [Bump Button]** - select a fader page on wings.
- **[Fader Page] & Rate Wheel** - rolls the selected fader page. (Ti/Eos/Gio)
- **[Fader Page] & [number]** - select a fader page on integral faders. (Ti/Eos/Gio)
- **[Fader Page]** - increments the fader page by 1.(Ti/Eos/Gio)
- **[Shift] & [Fader Page]** - decrements the fader page by 1. (Ti/Eos/Gio)
- **[Learn] & [Load]** - opens the selected fader's configuration tools.
- **[Off] & [Load]** - releases control of content, restoring to background and leave cue list with pending cue in tact.
- **[Release] & [Load]** - releases control of content, restoring to background, and resets cue list to top.
- **[Shift] & [Go]** or **[Shift] & [Back]** - cuts the pending cue or the previous cue.
- **[Shift] & [Load]** - to remove content from a fader.
- **[Shift] & [Stage]** - toggles Scroll Lock on and off.